

RUG PADS

CHOOSING THE RIGHT RUG PAD SIZE

Rug pad dimensions should be approximately 2" smaller than the rug. Pads can also be cut with household scissors if the size you need is not available or you have a smaller rug size.

Rug pad measurements should be based on the rug size, not including any decorative ends such as fringes.

To install, center the rug pad where you plan to place the rug, and lay the rug over the pad so that the rug overlaps by approximately one inch on all four sides.

Rug Size*	Use Rug Pad Size
-----------	------------------

3' x 5'	30 in. x 50 in.
---------	-----------------

2' x 8'	20 in. x 90 in.
---------	-----------------

4' x 6'	40 in. x 60 in.
---------	-----------------

5' x 8'	56 in. x 90 in.
---------	-----------------

6' x 9'	65 in. x 95 in.
---------	-----------------

8' x 10'	90 in. x 116 in.
----------	------------------


8' x 11'	90 in. x 128 in.
----------	------------------

9' x 12'	102 in. x 138 in.
----------	-------------------

10' x 14'	114 in. x 162 in.
-----------	-------------------

12' x 15'	138 in. x 174 in.
-----------	-------------------

*Rug sizes are approximate. Always round up to a larger size if your rug is in-between two sizes.



Why is a rug pad *essential* for every rug in the home?



Safety

Rug pads hold rugs in place, helping prevent bunching & slipping



Energy Efficiency & Comfort

Rug pads provide extra padding, increasing comfort, insulation, and sound proofing.



Protection

Rug pads protect the rug's weave, extending the life of the rug, and protecting your investment.